

NOTES:

- Follow these instructions when your Wet Location Rated Sconce does not include a gasket to be used between mounting surface and canopy.
- Please ensure mounting surface is flat.

REQUIRED TOOLS:

- Outdoor Silicon Caulking
- Flat Head Screwdriver
- Phillips Head Screwdriver

INSTALLATION INSTRUCTIONS

1. Clean area around Junction Box where Wet Location Rated Sconce is to be installed. Ensure clean area is slightly larger than Sconce Canopy and is dry before proceeding.
2. Wire and fully install Wet Location Rated Sconce. Consult electrician if necessary.
3. Apply Outdoor Silicone Caulking to the entire Canopy Rim where it meets the mounting surface except for a small section at the bottom center of the Canopy. This open section will allow any water to leave the Canopy if any has entered the Canopy.

