


DISCONNECT POWER BEFORE RE-LAMPING OR WIRING THE FIXTURE

READ ALL INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION.



FIXTURE PREPARATION


1. Remove the fixture, parts and parts bag(s) from the carton.

NOTICE:

 Before discarding the carton, double check to make certain that all parts are found.

FIXTURE INSTALLATION

- Attach the mounting ring with wing to the junction box. (The green screw should face the floor). Place the mounting ring with wing at the junction box and fasten using the round head screw.
- 2. Fasten the ground wire to the green or bare copper wire in the outlet box of the green screw on the mounting ring with wing.






FIGURE-01

Fasten the white fixture lead to the white wire in the outlet box.
Fasten the wires together with an approved fastener (wire nut). Starting about 1" below the fastener, tightly wrap the connection with electrical tape so that the connections seals the end of the fastener.

