

H431701 MARISSA PENDANT

ASSEMBLY AND MOUNTING INSTRUCTIONS

GENERAL

- WARNING-DISCONNECT POWER BEFORE RELAMPING OR WIRING THE FIXTURE. TURN OFF THE ENTIRE ELECTRICAL CIRCUIT TO WHICH THE LIGHTING FIXTURE IS ATTACHED
- INSTALLATION AND MAINTENANCE OF THIS FIXTURE SHOUILD BE COMPLETED BY A LICESNSED ELECTRICAN
- FAILURE TO INSTALL FIXTURE CORRECTLY COUD RESULT IN SEROIUS INJURY OR DEATH
- READ ALL INSTRUCTIONS BEFORE STARTING INSTALLATION.

- IF AN EXISTING FIXTURE IS BEING REPLACED, REMOVE IT AND NOTE TO WHICH WIRE IN THE OUTLET BOX THE ORIGINAL FIXTURE WAS ATTACHED.
- BEFORE DISCARDING THE CARTON DOUBLE CHECK THE PACKAGING TO MAKE SURE ALL PARTS HAVE BEEN FOUND.
- THIS FIXTURE WAS DESIGNED TO BE MOUNTED TO AN OCTAGON OUTLET BOX. THE BOX MUST BE SECURELY MOUNTED TO THE STRUCTURE OF THE BUILDING.

INSTALLATION

- STEP 1. Feed the wires through pipe stems, canopy, and mounting plate. Twist stem tightly onto the body. Keep adding additional stems to you desired height.
- STEP 2. Slide in the canopy onto the stem, and thread it onto the stem
- STEP 3. Attach the mounting plate to the outlet box by using the mounting screws.
- STEP 4. Trim excess wire to min 6" beyond the canopy, strip each wire to 5/8".
- STEP 5. Fasten bare ground wire to ground wire from the wall outlet box (usually green or copper color) or connect ground wire to green screw on the mounting plate.
- STEP 6. Connect the neutral (white) fixture wire coming from the fixture base to neutral (usually white) outlet wire. Fasten both wires together with a plastic wire nut and tightly wrap the wire nut with electrical tape.

- STEP 7. Repeat the previous step with the hot (black wires). Make sure there are no exposed wires or strands that could cause a dangerous short circuit.
 - FAILURE TO CONNECT THE APPROPRIATE WIRES CORRECTLY COULD RESULT IN SEROIUS INJURY OR DEATH!
- STEP 8. Place the canopy with the fixture over the outlet box and fasten it by the ball nuts.
- STEP 9. Attach the glass shade onto the glass holder, secure it with the socket ring.
- STEP 10. Install the lamp(s). The fixture is rated for 60-watt type T10 lamp.

DO NOT EXCEED RECOMMENDED WATTATE!

STEP 11. Restore power to the circuit at breaker or fuse-box.

DIMMING

The fixture can be controlled by a wall dimming device. Only use triac/electronic dimmer. Make sure carton is marked for use with LED compact fluorescent-incandescent light source only. These can be

provided by your local electrical distributor, home center, or hardware store.


CLEANING

Please clean with a soft, dry cloth ONLY! Do not use cleaning products.



H431701 MARISSA PENDANT

ASSEMBLYANDMOUNTINGDIAGRAM



WIRE NUT/TAPINGDIAGRAM

