


DISCONNECT POWER BEFORE RELAMPING OR WIRING THE FIXTURE.

READ ALL INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION.



• For your safety be certain that all circuit breakers controlling outdoor lighting and other equipment are GFI Breakers

FIXTURE PREPARATION

1. Remove the fixture, parts and parts bag(s) from the carton.

NOTICE:

Before discarding the carton, double check to make certain that all parts are found.

2. This fixture is designed to be mounted on a standard round or octagon box. The box must be securely mounted to the structure of the building. The crossbar and hardware supplied should be used to correctly adjust and level the fixture

FIXTURE INSTALLATION

- 1. Remove the (4) screws from the ring of the fixture cage.
- Separate the cage halves.
- 2. Attach the mounting ring to the outlet box. (The green screw should face out).
- Adjust the screws on the crossbar so that they extend 3/16" beyond the back of the fixture. Lock the screws in place with the hex nuts
- 4. Fasten the ground wire to the green or bare copper wire in the outlet box or to the green screw on the crossbar.

WARNING

Never fasten the ground wire to the black or "hot" wire! Failure to follow this instruction could result in serious injury or death!

5. Fasten the white fixture lead to the white wire in the outlet box. Fasten the wires together with an approved fastener (wire nut). Starting about 1' below the fastener, tightly wrap the connection with electrical tape so that the connection seals the end of the fastener.

