
F2495FI F7135 INSTALLATION INSTRUCTIONS



WARNING

DISCONNECT POWER BEFORE RELAMPING OR WIRING THE FIXTURE. READ ALL INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION.



- Attach the mounting ring to the 10-24 STUDS in the outlet box.DO NOT USE THE BOX "EARS". Thread nipple into the crossbar and hex nut onto the nipple. Place the canopy against the ceiling. Adjust the nipple so that 1/4" of thread is exposed beyond the canopy. Tighten the hex nut against the crossbar.
- 3. Fasten the ground wire to the green or bare copper wire in the outlet box or to the green screw on the crossbar.



Never fasten the ground wire to the black or "hot" wire! Failure to follow this instruction could result in serious injury or death!

4. Fasten the white fixture lead wire to the white wire in the outlet box. Fasten the wires together with an approved fastener (wire nut). Starting about 1' below the fastener, tightly wrap the connection with electrical tape so that the connection seals the end of the fastener.

Make sure that there is no exposed wire or strands that could cause a dangerous short circuit!	
electrical tape	
approved fasten (wire nut)	er

- 5. Connect the black fixture lead wire to the black wire in the outlet box. Fasten the joined wires as in step 5.
- 6. Thread the SAFETY CABLE down through alternating links of chain.
- **7.** Slide the canopy and ring up the chain to the outlet box. Secure the canopy in place against the ceiling.
- **8.** Place the glass panel onto the holder of inner cage frame and hold it using the metal disk, fasten them using allen screw and allen wrench.
- **9.** Install the lamps (light bulbs). NOTE: This fixture is rated for Max 60 watt type B, BA, C or CA lamp.

