


# 

### DISCONNECT POWER BEFORE RELAMPING OR WIRING THE FIXTURE READ ALL INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION.




## NOTICE

- The important safeguards and instructions outlined on this sheet cannot cover all possible conditions and situations that
  may occur. it must be understood that common sense, caution and care factors that cannot be built into any product.
  Caution and care must be supplied by the person(s) installing, operating and caring of this lighting fixture.
- This fixture is designed to be mounted on a correctly installed standard round or octagon box or a through wiring box
  with a plaster frame. The box must be securely mounted to the structure of the building. The crossbar and hardware supplied
  should be used. directly mounting the fixture to the outlet box may make it impossible to correctly align the fixture.

### **FIXTURE PREPARATION**

1. Remove the fixture, glass diffuser and parts bag(s) from the carton.



2. Determine the overall desired length of the fixture. Adjust the length of the power cord and safety cable according to your desired length of the fixture. Tighten the grip lock after reaching the desired length then cut off the excess wire. Thread the Allen screw to adjust the tightness of the cable stay that will hold both the cable wire and power cord in place.

### **FIXTURE INSTALLATION**


 Attach the mounting plate to the junction box using the mounting screws. The green screw should face the floor. Back out the screws 1#2 turn to allow the ring to rotate. Attach the safety cable to the structure or brace. See figure-1.

NOTICE: THIS LUMINAIRE MUST BE MOUNTED OR SUPPORTED INDEPENDENTLY OF AN OUTLET BOX.




REFER TO THE ILLUSTRATION FOR CORRECT AND SAFE INSTALLATION OF SAFETY CABLE. FAILURE TO FOLLOW THIS INSTRUCTION COULD RESULT HARM/DAMAGE TO THE FIXTURE, PROPERTY AND/OR PERSON(S)!

2. Cut off the excess ground and fixture wire 6" beyond the canopy. Strip 1#2" of insulation from the ends of the wire. Twist the wire stands together.





3. Fasten the ground wire to the green or bare copper wire in the junction box or the green screw on the mounting ring.



SPECIAL TOOL